

# WINTER *time*



# VÁNOCE

T0017, T0041



**OPT2129.T0017**  
flat plate 29 cm



**OPT2129.T0041**  
flat plate 29 cm



**OPT1927.T0017**  
bowl 27 cm



**OPT2120.T0017**  
flat plate 20 cm

**REB0618.T0017**  
cup 18 cl




**PRI1714.T0017**  
saucer 14 cm



**REB0625.T0017**  
cup 25 cl

*decolab*



decolab

GOLDEN PINE A0016



MNA2124.A0016  
flat plate 24 cm



MNA2127.A0016  
flat plate 27 cm



MNA1924.A0016  
deep plate 24 cm



VIC0820  
cup 20 cl

VIC1716.A0016  
saucer 16 cm



VIC1716.A0016  
saucer 16 cm

# decolab CESMÍNA K0065



JOS0218.K0065  
cup 18 cl



JOS1714.K0065  
saucer 14 cm



ISC2121.K0065  
flat plate 21 cm



ISC2130.K0065  
flat plate 30 cm



# VERONA X9250 *gold*



VER0825.X9250  
coffee cup 25 cl



VER1715.X9250  
saucer 15 cm

VER0808.X9250  
espresso cup 08 cl



VER1712.X9250  
saucer 12 cm



VER2119.X9250  
plate 19 cm



VER2125.X9250  
plate 25 cm



VER1924.X9250  
deep plate 24 cm



# SWEATER PATTERN

**X8823**  
*red*



**EHS0627.X8823**  
mug 25 cl



**EHS0645.X8823**  
mug 45 cl



**AKZ0640.X8823**  
mug 40 cl



**AKZ0844.X8823**  
mug 40 cl



**ACT1923.X8823**  
deep plate 23 cm



**BAS2120.X8823**  
flat plate 20 cm



**BAS2126.X8823**  
flat plate 26 cm



**BAS2131.X8823**  
flat plate 31 cm

**X8826**  
*green*



**EHS0627.X8826**  
mug 25 cl



**EHS0645.X8826**  
mug 45 cl



**AKZ0640.X8826**  
mug 40 cl



**AKZ0844.X8826**  
mug 40 cl



**ACT1923.X8826**  
deep plate 23 cm



**BAS2120.X8826**  
flat plate 20 cm



**BAS2126.X8826**  
flat plate 26 cm



**BAS2131.X8826**  
flat plate 31 cm



**4LID1DC0000H**  
lid silicon




**4BELT1SBC21000H**  
belt silicon



**COF0740.X8923**  
mug 40 cl



**COF0740.X8925**  
mug 40 cl



**COF0740.X8823**  
mug 40 cl



**COF0740.X8826**  
mug 40 cl

**ANYWHERE YOU GO**



**CRE2226.T0058**  
flat plate 26 cm